## **Panasonic**

### Advanced Hybrid System

### **KX-TA624**

# Installation Manual Addendum for KX-T77 and KX-T73 Series

This Installation Manual Addendum provides the additional information for the KX-T77 and KX-T73 Series Telephones and the Panasonic Advanced Hybrid System, KX-TA624.

# Table of Contents

System Components Table	3
Features	
Buttons on Proprietary Telephones	3
Call Log, Incoming	4
Caller ID	3, 4
Caller ID Call Waiting	4
DSS Console	4
Handset/Headset Selection	4
Hands-free Answerback	4
Hands-free Operation	4
Room Monitor	4
Station Programming	4
System Programming with a Proprietary Telephone	ne4
System Programming	
Using the Overlay	5
Viewing the display	7
[002] System Password	10
[011] System Speed Dialing Name Setting	8
[309] Emergency Dial Number	
[968] KX-T77xx Incoming Lamp Control	9
<b>Programming Tables</b>	
[002] System Password	10
[011] System Speed Dial Name Setting	11
[309] Emergency Dial Number	10
[968] KX-T77xx Incoming Lamp Control	10

### **System Components**

The following Panasonic Proprietary Telephones (PTs) and a DSS console are available for KX-TA624.

#### **System Components Table (Additional)**

	Model	Description	
Telephone	KX-T7735	Proprietary Telephone with 16-character/3-line and back-lit display and Message/Ringer Lamp	
	KX-T7730	Proprietary Telephone with 16-character/1-line and back-lit display and Message/Ringer Lamp	
	KX-T7720	Proprietary Telephone with Message/Ringer Lamp	
	KX-T7750	Proprietary Telephone with Message/Ringer Lamp and MONITOR button	
	KX-T7335	Proprietary Telephone with 16-character/1-line and back-lit display	
	KX-T7320	Proprietary Telephone	
	KX-T7350	Proprietary Telephone with MONITOR button	
Optional Equipment	KX-T7740	DSS Console	

#### **Features**

#### **Additional Information for Features**

The additional information for Features

Features	Additional Information
Buttons on Proprietary Telephone	As for Buttons on the KX-T7735, KX-T7730, KX-T7720, KX-T7750, KX-T7335, KX-T7320 and KX-T7350, please refer to the User Manual Addendum for KX-T77 and KX-T73 Series.
Caller ID	<ul> <li>The conditions are added.</li> <li>An assigned name in program [011] "System Speed Dialing Name Setting" will be displayed when the caller's telephone number matches one of System Speed Dialing numbers assigned in program [001] "System Speed Dialing Entry" and a Telephone Company does not provide the caller's name.</li> <li>If a Telephone Company provides a caller's name, the name from the Telephone Company will be displayed even when a name assigned in program [011] is effective.</li> </ul>

The following features are available with PTs depending on the type of the KX-T77 or KX-T73 series.

Features	T7735 T7335	T7730	T7720 T7320	T7750 T7350	T7740
Call Log, Incoming	~	~			
Caller ID/ Caller ID Call Waiting	~	~			
DSS Console*1					<b>V</b>
Handset/Headset Selection	V	~	(for T7720)	(for T7750)	
Hands-free Answerback	~	~	~		
Hands-free Operation	~	~	~	<b>/</b> *2	
Room Monitor	~	~	~		
Station Programming	The following	ng programmi	ing items are ava	ailable.	
Call Waiting Tone Type Assignment	~	~	~	V	
Flexible Button Assignment	~	~	·	~	
Intercom Alert Assignment	~	~	~	~	
Outside (CO) Line Ringing Selection	~	~	~	~	
Preferred Line Assignment — Incoming/Outgoing	V	~	~	V	
Station Programming Data Default Set	V	~	~	V	
Self-Extension Number Confirmation	V	~			
System Programming with a Proprietary Telephone	~	~			

#### <u>Note</u>

As for other features, please refer to the Installation Manual.

<sup>\*1</sup> The KX-T7740 is available for the KX-TA624. For details about DSS Console, please refer to the Installation Manual.

<sup>\*2</sup> The MONITOR button on the KX-T7750 or KX-T7350 can be used for hands-free dialing operation, etc., but cannot be used for a hands-free conversation.

### **System Programming**

A display PT (KX-T7735, KX-T7730 or KX-T7335) is required for system programming.


#### **Using the Overly**


A programming overlay is packed with the telephone at the factory. This overlay should be used at all times during programming. The features of the telephone keys change during programming as follows. (The original features are in parentheses.)

<b>During Normal Operation</b>	During Programming
(PAUSE)	PAUSE
(AUTO ANSWER/MUTE)	SELECT
(AUTO DIAL/STORE)	STORE
(FLASH/RECALL)	FLASH
(INTERCOM)	SECRET (T7735 or T7730) <b>←</b> (T7335)
(CONF or <b>◄</b> )	◆ , − (T7735 or T7730)
(FWD/DND or ▶)	(T7735 or T7730)
(MESSAGE)	-, <b>➡</b> (T7335)
(TRANSFER)	CLEAR
(REDIAL or ▲)	PREV (PREVIOUS)
(HOLD)	END
(SP-PHONE or <b>▼</b> )	NEXT
(PROGRAM)	PROGRAM

#### **Location of Controls with Overlay (Additional)**

The picture below shows the features of the buttons of the KX-T7735 or KX-T7335 during programming.





<KX-T7735>

<KX-T7335>

#### <u>Note</u>

The KX-T7730 has the same overlay as the KX-T7735.

#### Viewing the Display

The display gives you helpful information, such as the next step, previous entries, etc.

The KX-T7735 utilizes three information lines for programming.

The KX-T7730 utilizes one information line for programming.

The display capacity is 16 digits. If your entry is longer than 16 digits, the user can scroll the display by pressing the Navigator Key  $(\blacktriangleleft \triangleright)$ , or the  $\blacksquare \triangleright$  or  $\blacktriangleleft \blacksquare$  button.

#### <Display Example>

Display	Button for Operation	Move to:	
	PREV (REDIAL) or ▲ (Navigator Key)	001 Speed Dialing 99:81924857986	
001 Speed Dialing 00:9123456789012	► / ■► (Navigator Key or FWD/DND button)	001 Speed Dialing 00:1234567890123	
	NEXT (SP-PHONE) or ▼ (Navigator Key)	001 Speed Dialing 01:Not Stored	
	(Navigator Key or CONF button)	131 VM2(APT)Port	
200 Hold Recall Time	► / ■► (Navigator Key or FWD/DND button)	201 Transfer Recall	
	NEXT (SP-PHONE) or ▼ (Navigator Key)	200 Hold Recall Time Time:30 sec	

#### [011] System Speed Dialing Name Setting (Additional)

#### **Description**

Assigns a name to each System Speed Dialing number. The name will be displayed when making a call by using the System Speed Dialing feature. It will also be used for the Caller ID feature.

#### Selection

Speed Dial Number: 00-99Name: 16 characters (max.)

#### **Default**

All speed dial numbers — Not stored

#### **Programming**

1. Enter 011.

Display: Speed Dial Name

2. Press NEXT.

Display: Speed NO? →

**3.** Enter a speed dial number.

To enter speed dial number 00, you can also press NEXT.

```
Display example: 00:Not Stored
```

4. Enter a name.

For entering characters, please refer to "4.1.3 Entering Characters" in the Installation Manual.

To delete the current entry, press **CLEAR**.

To change the current entry, press **CLEAR** and enter the new name.

- 5. Press STORE.
- **6.** To program another speed dial number, press **NEXT** or **PREV**, or **SELECT** and enter the desired speed dial number.
- 7. Repeat steps 4 through 6.
- 8. Press END.

#### **Conditions**

- Speed dial numbers are programmed in program [001] System Speed Dialing Entry.
- Each name has a maximum of 16 characters.

#### Feature References — in the Installtation Manual

System Speed Dialing

### [968] KX-T77xx Incoming Lamp Control (Additional)

#### **Description**

Enable or disable to flash the Message/Ringer Lamp when an extension is in the following status:

- A call is waiting when Call Waiting Tone 1 is assigned.
- A call is incoming to Doorphone 4.
- A call with Caller ID information is waiting during a conversation
- No ringing when a call is incoming to a doorphone, but chiming a doorbell/door chime.

This programming is available for the KX-T77 series only.

#### **Selection**

• **Disable** (Message/Ringer Lamp — Off)/**Enable** (Message/Ringer Lamp — Flashing)

#### **Default**

Disable

#### **Programming**

1. Enter 968.

```
Display: T77xx Incom.Lamp
```

2. Press NEXT.

```
Display example: Disable
```

- 3. Keep pressing **SELECT** until the desired selection is displayed.
- 4. Press STORE.
- 5. Press END.

#### **Conditions**

None

#### **Feature References**

— in the Installtation Manual

Call Waiting

Caller ID Call Waiting

Doorphone Call

— in the Additional Instructions for the Doorbell/Door Chime Users

Doorbell/Door Chime

### **Additional and Changed Information for System Programming**

System Programming	Additional and/or changed Information
[002] System Password	Selection • Password: 4 through 7 digits (Note: The range of the password has changed from 0000-9999 to 0000-9999999.)
[309] Emergency Dial Number	<ul> <li>Selection</li> <li>Code number: 1-5</li> <li>Emergency number: 24 digits (max.) (Note: The maximum size of the emergency number has changed from 11 to 24 digits.)</li> </ul>

### **Programming Tables**

### [002] System Password

	Default			Parameter: $4 - 7$ digits, consisting of $0 - 9$
1	2	3	4	

### [309] Emergency Dial Number

Code No.	Parameter : 24 digits (max.), consisting of 0 – 9
Default	Code 01=911 Other codes=Not Stored
1	
2	
3	
4	
5	

### [968] KX-T77xx Incoming Lamp Control

	Enable	Disable
Default		<b>/</b>
Change		l

### [011] System Speed Dial Name Setting

SPD no.	Name (max. 16 characters)	SPD no.	Name (max. 16 characters)	SPD no.	Name (max. 16 characters)	
Default	All: Not stored					
00		40		75		
01		41		76		
02		42		77		
03		43		78		
04		44		79		
05		45		80		
06		46		81		
07		47		82		
08		48		83		
09		49		84		
10		50		85		
11		51		86		
12		52		87		
13		53		88		
14		54		89		
15		55		90		
16		56		91		
17		57		92		
18		58		93		
19		59		94		
20		60		95		
21		61		96		
22		62		97		
23		63		98		
24		64		99		
25		65				
26		66				
27		67				
28		68				
29		69				
30		70				
31		71				
32		72				
33		73				
34		74				

